

# Mech 262 – Textbook Guide: Forced and Natural Convection

## **Chapter 19: Forced Convection (775)**

(External Flow)

- 19-3: Parallel Flow Over Flat Plates (780)
  - Flat Plate with Unheated Starting Length (782)
  - Uniform Heat Flux (783)
- 19-4: Flow Across Cylinders and Spheres (786)
  - Table 19-2: Forced Convection Over Cylinders (788)

(Internal Flow)

- 19-5: General Considerations for Pipe Flow (791)
  - Entry Lengths (794)
- 19-6: General Thermal Analysis (795)
  - Constant Surface Heat Flux ( $q_s = \text{constant}$ ) (796)
  - Constant Surface Temperature ( $T_s = \text{constant}$ ) (797)
- 19-7: Laminar Flow in Tubes (800)
  - Table 19-3: Laminar Flow in Tubes (802)
  - Constant Surface Heat Flux (801)
  - Constant Surface Temperature (802)
  - Laminar Flow in Noncircular Tubes (802)
  - Developing Laminar Flow in the Entrance Region (803)
- 19-8: Turbulent Flow in Tubes (805)
  - Developing Turbulent Flow in the Entrance Region (807)
  - Turbulent Flow in Noncircular Tubes (807)
  - Flow through Tube Annulus (808)
  - Heat Transfer Enhancement (808)

## **Chapter 20: Natural Convection (831)**

(External Flow)

- 20-3: Natural Convection Over Surfaces (838)
  - Table 20-1: Natural Convection Over Surfaces (840)
  - Vertical Plates ( $T_s = \text{constant}$ ) (839)
  - Vertical Plates ( $q_s = \text{constant}$ ) (839)
  - Vertical Cylinders (841)
  - Inclined Plates (841)
  - Horizontal Plates (842)
  - Horizontal Cylinders and Spheres (842)

(Internal Flow)

- Natural Convection Inside Enclosures (846)
  - Horizontal Rectangular Enclosures (847)
  - Inclined Rectangular Enclosures (848)
  - Vertical Rectangular Enclosures (849)
  - Concentric Cylinders (848)
  - Concentric Spheres (850)
  - Combined Natural Convection and Radiation (850)