



TANK

EXPANSION TANK

PRESSURE SWITCH

ISOLATION VALVE(S)

PIPE

AAV (AUTOMATIC AIR VENT)

PRV (PRESSURE RELIEF VALVE)

ISOLATION VALVE (BALL)

FLOW TO HOUSE

DRAIN VALVE
(HOSE BIB)

WATER LEVEL

CHECK VALVE

PUMP

WELL

WELL WATER SYSTEM